



MegaPower 48 Plus

Matrix Switcher/Controller System

Features That Make a Difference:

- Universal MEU supports both NTSC and PAL
- 3 flexible expansion modes using a primary/secondary configuration of up to 7 systems and 288 cameras
- Ethernet Cat 5 IP connection for multi-matrix communications and system setup
- EASY 48 configuration and monitoring software for Windows® XP, 2000, 95/98 and NT® 4.0-based systems
- Dome ping test and status display
- RS-422 dome support, including simplex RS-422
- DirectSet function control menu for SensorNet or RS-422 domes with ControlCenter 200/300 DirectSet key or ADTTE, and AD2088, and AD2089 site keys
- 48 video inputs
- 16 video outputs, 8 with text overlay
- Optional Unshielded Twisted Pair (UTP) Adaptor Module allows installation with simple UTP cable for video
- Full embedded system menus for easy setup
- Recorder control
- User-defined macros
- 4096 preset titles and 250 alarm titles
- Dedicated alarm programming tables differentiate between alarm sources
- RS-232 inputs expandable to 32
- 64 system tours and 64 salvos

MegaPower 48 Plus is an IP-enabled matrix switcher/controller system that can operate as a standalone system or as part of a network. Choose from one of three expansion modes and grow your system by up to 288 inputs. Whether used as a centralized or distributed system, MegaPower 48 Plus can be cost-effectively installed and optimized for the most challenging of site requirements.

The new EASY 48 system configuration software is a user-friendly MS Windows application that permits the administrator to program MegaPower 48 Plus either on-site or remotely via Ethernet or RS-232. Use it to remotely check the system status of cameras and monitors via an Ethernet connection or to back up and restore system data.

The slim modular wall-mount design saves space and reduces cabling costs by letting you install MegaPower 48 Plus in the location that is most central to your cameras. Because it doesn't have to be rack mounted in a control room, MegaPower 48 Plus can be installed anywhere in your facility – even an electrical closet, or maximize the space and fit in more devices in your standard rack by installing it at 90° angle behind other equipment. You can also rack mount MegaPower 48 Plus at other angles to facilitate easy cable connections with the optional rack mount kit.

features

System Expansion

Systems are expanded with a primary-to-secondary relationship. There are three modes of expansion, using Ethernet for command and control. If inter-matrix communication is disrupted, all secondary units continue functioning locally and the primary provides status to users of the fault condition.

Mode 0: Basic system, 48 video inputs, 16 full crosspoint video outputs.

Mode 1: The primary unit has 16 video trunk lines from each of up to three secondary units, providing 16 full crosspoint video outputs with up to 144 video inputs.

Mode 2: The primary unit has 12 video trunk lines from each of up to four secondary units, providing 12 full crosspoint video outputs with up to 192 video inputs. Each secondary has three local outputs with full crosspoint video switching of local cameras.

Mode 3: The primary unit has eight video trunk lines from each of up to six secondary units, providing 8 full crosspoint video outputs with up to 288 video inputs. Each secondary has seven local outputs with full crosspoint video switching of local cameras.

Expansion Mode Chart

Mode	PRIMARY		SECONDARY			KEY-BOARDS	ALARMS			
	Inputs	Outputs	Units	Outputs Per	Total Outputs		Patch Panel	Dome	Video Loss	RS232 Alarms
0	48	16	0	N/A	N/A	32	16	192	48	512
1	80	16	1	0	0	64	32	320	80	512
	112	16	2	0	0	96	48	448	112	512
	144	16	3	0	0	128	64	576	144	512
2	84	12	1	3	3	64	32	336	84	512
	120	12	2	3	6	96	48	480	120	512
	156	12	3	3	9	128	64	624	156	512
	192	12	4	3	12	160	80	768	192	512
3	88	8	1	7	7	64	32	352	88	512
	128	8	2	7	14	96	48	512	128	512
	168	8	3	7	21	128	64	672	168	512
	208	8	4	7	28	160	80	832	208	512
	248	8	5	7	35	192	96	992	248	512
	288	8	6	7	42	224	112	1152	288	512

Camera Site Control

Users can control domes, pan/tilts, motorized lenses, auxiliary outputs, presets and patterns at suitably-equipped camera sites via SensorNet, RS-422 and Manchester outputs. To better support legacy SpeedDomes and installations that use simplex RS-422 communication, the system allows presets to be stored in the dome.


System Programming

On-screen menus enable you to program system features from any full-system keyboard. Operators can use the monitors with text overlay to program the system. In addition, the EASY 48 system configuration software enables you to custom-configure using computers running Windows XP, 2000, 95/98 or NT 4.0. This software package provides simplified setup, archiving and retrieval of setup as well as the ability to load and retrieve that data via Ethernet or RS-232.

RS-232 Communications

Eight direct ports allow standard communication with keyboards, alarm interface units, recorder control devices, computers, third party devices, modems (for text message paging), and more. Each port can expand to four ports with an optional port expander.

Mode 3 Example



Selectable On-Screen Text

Each of the first eight monitors can display the date/time, video input number, 16-character user-definable video input or preset title, alarm title, monitor status, and secondary status.

Macro Control

The system's powerful macros allow each operator to customize their own ControlCenter 1100 or AD2088/AD2089 workstations to perform a multitude of tasks via simple, intuitive, easy-to-remember keystrokes.

Recorder Control

Users can control all of the standard recorder functions directly from any suitably-equipped keyboard – play, stop, pause, record, rewind, fast forward, and eject.

Pseudo Camera Numbers

Users can assign a four digit number to replace the default video input number for each video input, making it easier to identify cameras in multiple level buildings and similar situations.

System and Monitor Tours

A tour is a sequence of video inputs with each input featuring an individual dwell time, a preset/pattern and an auxiliary action. Tours can run forward or in reverse. Video partitioned from a monitor is skipped.

Event Timers

There are 35 user-programmable times available. These times may be independently designated for multiple days of the week to automatically call up system tours to video outputs. Event timers also enable you to activate and deactivate alarm contacts based on the time of day.

Salvo Switching

Salvo switching allows multiple video inputs to be called simultaneously to multiple contiguous video outputs. Sixty-four individual groups (salvos) consisting of up to 16 video inputs (each with a preset, pattern and/or auxiliary action) can be called either manually or as part of a system tour.

Automatic Alarm Callup

Alarm inputs can be programmed to call any video input or salvo to any one or more video outputs. For each alarm input, users can define a camera, preset, pattern, wireless text message, salvo, alarm message and/or auxiliary action (with individual dwell time for each to accommodate sequencing alarms). In addition, two local patch panel relays can be triggered upon any alarm event. Any combination of 25 alarm display/clearance methods may be selected independently for each video output. Alarms can hold or sequence on outputs. Blocks of monitors can be defined; normal, automatic and instant clearing are supported.

Internal Video Loss Detection

Video loss detection is standard on all video inputs. Upon video loss, a system alarm is generated. Enabling video loss detection occupies video output 16.

Text Message Paging on Alarm

MegaPower 48 Plus can transmit text messages to cellular phones and pagers when an alarm occurs, alerting users with a detailed description of the event and instructions for how to respond. With alarm programming, a single event can trigger multiple unique messages to one or more recipients. You can program as many as 64 different pager profiles and define up to 250 unique text messages for transmitting. The paging feature supports the TAP protocol via an external modem (not supplied).

Status Output

System status output via an RS-232 printer port may be programmed to output both the occurrence and clearing of all alarms as well as power status and monitor messages.

System Partitioning

System flexibility is further enhanced by defining authorized access to keyboards, video inputs and video outputs. System partitioning includes:

- Keyboard-to-Monitor Access: Restricts selected keyboards from accessing selected video outputs.
- Monitor-to-Camera Access: Restricts selected video outputs from displaying selected video inputs.
- Keyboard-to-Camera Access: Restricts selected keyboards from calling or controlling selected video inputs.
- Keyboard-to-Camera Control Access: Allows selected keyboards to access views from certain cameras but restricts those keyboards from controlling the cameras.

Password and Priority Operation

Keyboards or users can be assigned one of eight priority levels for controlling remote camera sites. Up to 64 user codes, each with a unique password, can be assigned to operators. Access to certain system features may be restricted depending on a user's priority level.

Diagnostics and Dome Information Screens

Built-in diagnostics clearly indicate power status and system health, allowing you to determine the status of the system's internal components. The dome information screen shows the video detection status, dome mnemonic, dome protocol, dome software version and whether the dome is responding to the system polls for each camera on the system. For troubleshooting purposes, the dome ping test screen allows the installer to verify the integrity of SensorNet and RS-422 communications and display dome firmware number, mnemonic, serial number and production date.

Flash Memory Module for Data Backup

The system is comprised of a passive patch panel for all system wiring and a removable main electronics unit (MEU). There is also a flash memory module that is separate from the MEU and lets you automatically back up data without a PC. This allows you to replace a system and restore the existing data in less than one minute.

Digital Video Management System Control

The AD2089 keyboard allows you to control Intellex digital video management systems including playback of archived video. This feature requires Intellex and Network Client v4.04.

Model Numbers

Each MegaPower 48 Plus system consists of a wall-mount assembly (bracket and patch panel assembly), main electronics unit (Universal, NTSC or PAL), pre-wired transformer assembly (selectable voltage), and documentation kit including CD with various languages.

ADMP48-E MegaPower 48 Plus, Universal

Optional Accessories

Keyboards

ADCC1100 - MegaPower 1100 keyboard

with smart card and macro keys

ADTTE - Touch Tracker keyboard

ADCC0200P - ControlCenter 200 keyboard

with 2-axis joystick

ADCC0300P - ControlCenter 300 keyboard

with joystick and programming access

AD2089 - Full system keyboard

with macro keys and video recorder control (DVR or VCR)

Other Accessories

AD2081, AD2081-1 Port Expander

Expands one RS-232 port on a system into four ports, providing connections to multiple system keyboards.

AD2096A, AD2096-1 Alarm Interface

Monitors up to 64 alarm inputs and provides RS-232 ASCII alarm commands to the system. Up to eight units can be cascaded on a RS-232 line.

AD2031, AD2031-1 Switcher Follower

Activates relays when designated video inputs are called to designated video outputs. It interfaces via Manchester and provides up to 32 Form A relays that can be grouped in series and addressed to a single video output or in two groups of 16 relays for two specific video outputs.

AD2032, AD2032-1 Alarm Responder

Activates relays when associated video outputs are in an alarmed condition. Interfaces via Manchester and provides up to 32 Form A relays.

AD2033, AD2033-1 Auxiliary Follower

Activates relays when a specific auxiliary is triggered either manually or automatically for an associated video input. Interfaces with matrix switcher/controllers and provides up to 32 Form A relays via Manchester. Multiple units can be cascaded together.

VR48RKIT Rack Mount Kit

This enables the MegaPower 48 Plus system to be rack mounted in a standard 19-inch EIA rack mount.

ADACTP01BNC - Unshielded Twisted Pair Adaptor Module

This allows installation with simple UTP cable for video lines.

VRCMKIT Cable Brackets

Each kit contains three additional cable management brackets.

Operational

Bandwidth 10 MHz

Frequency Response ± 1.0 dB to 6 MHz

S/N Ratio 60 dB (Vp-p vs. Vrms noise)

Crosstalk

Adjacent Channels ≤ -55 dB (at 3.58 MHz)

Input to Input ≤ -70 dB (at 3.58 MHz)

Differential Delay $\pm 1.0^\circ$

Differential Phase $\leq 0.5^\circ$

Differential Gain $\leq 1.5\%$

Tilt $\leq 2.0\%$

Gain Unity ± 1 dB

Return Loss

Input/Output 40 dB

DC Level (Video Signal) 0 Volts (± 0.1 V typical)

Switching Complete switching of crosspoint matrix
EIA RS-170 and NTSC, CCIR and PAL

Switching Speed Less than 20 ms (typical)

On-Screen Text Date/time, video input number, video

Outputs 1-8 Input or preset title (16 characters), monitor
status, alarm title (48 characters)

Character Set English, French, Italian, German, Spanish,
Portuguese

Video Inputs 48 BNC composite, 0.5 to 2.0 Vp-p

Video Outputs 16 BNC composite, 1.0 Vp-p (with nominal input)

RS-232 Eight 8-pin RJ-45 optional port expander
extends each port to four

Network Ethernet, IEEE 802.3, 10 Mbps, TCP/IP

Utilization $< 2.5\%$

Connection RJ-45, Cat 5 wiring

Protocol IP, fixed addresses, supports gateway
connection

External Modem One DB9 connector (Hayes AT compatible)

SensorNet Six ports through terminal screw connectors

SEC RS-422 Six ports through terminal screw connectors

Manchester One port through terminal screw connectors

Alarm Inputs 16 inputs through two 16-pin terminal
screw connectors

Relay Outputs Two Form-C relays through two 3-pin terminal
screw connectors

Power One 3-pin terminal screw connector

Flash Memory Module One 8-pin header

Electrical

Power Source 12 VDC external power supply, universal

Supply Voltage 100-240 VAC, 50-60 Hz

Power Requirements5 amps, 42 VA

Mechanical

Mounting Vertical wall or 19-inch EIA rack mount

Dimensions (H x W x D) 50.8 x 43.8 x 8.9 cm (20 x 17.3 x 3.5 in)

Unit Weight

Wall Bracket 1.54 kg (3.4 lbs)

Patch Panel Assembly 1.72 kg (3.8 lbs)

Main Electronics Unit 2.72 kg (6.0 lbs)

Total Weight 5.97 kg (13.2 lbs)

Transformer Weight 2.17 kg (4.8 lbs)

Color Black

Environmental

Operating Temperature 0° to 50° C (32° to 122° F)

Humidity 5 to 95% RH (non-condensing)

Storage Temperature -40° to 70° C (-40° to 155° F)

Regulatory

Emissions FCC Part 15, Class A

EN55022 (CE)

Immunity EN50130-4 (CE)

Safety UL1950

CSA 22.2, No. 950

(cUL) EN60950 (CE)

EASY 48

PC Recommendation Windows XP, 2000, NT 4.0 or 95/98

800 MHz Processor

1 GB hard disk space

256 MB RAM

