




Membrane

Removal & Replacement



Membrane Removal & Replacement



Removal

- Ease the membrane off the clear cup gently

Replacement

- Stretch the replacement membrane over the clear cup.