



Battery Removal & Replacement



Note:

When replacing the battery, ensure that the unit is switched off before opening the back cover.











Battery Removal

& Replacement

Battery pack LED

Flashing Red/Green: Detecting level of charge

Solid Red: Charging

Solid Green: Fully charged

Flashing Red: Fault

Removal

Unclip and remove the used battery.

Replacement

Warning:

Do not charge the battery while it is in place in the unit.

- To charge, connect the battery pack to the USB power supply using the supplied charger.
- Once the battery is charged clip the battery pack into the battery compartment.
- Do not force the battery into place it should only be inserted without force.

